

# Space Situational Awareness (SSA)



## Introducing Earthfence



- Thoth is pleased to offer Earthfence, a unique digital radar solution for Space Situational Awareness (SSA).
- Earthfence comprises a software based sensor, data management and analysis system with COTS hardware configuration optimized for SSA.
- With the steady increase of satellites, the risk of collision is increasing. Collisions can destroy assets and create more debris that could eventually render some orbits unusable.
- Users gain the improved SSA required for operations in an environment with an exponentially growing number of objects.
- Geostationary and constellation satellite operators extend the lifetime of their assets by avoiding collisions with other spacecraft and debris.

## Features

- A digital C-band pulse compression radar system installed on Thoth's 46 m (150 ft) parabolic antenna provides a unique tool for surveillance of space.
- Pulse compression optimizes the trade-off between radar range capabilities and radar resolving power.
- Variable pulse modulation, duration, bandwidth, and repetition interval are fully software customizable to maximize performance for particular applications.





- **Scalable sensor architecture** deployable across networks and orbit classes.
- **Target extraction** data optimized for multi-core platforms.
- **Target visualisation.**
- **Monitor orbit crowding** by neighbouring spacecraft, eavesdropping satellites, space debris.
- **Proven Data Accuracy** against calibration targets (IS-907 spacecraft residual, pictured right).

Item	Value	Unit
Range	50,000	km
Range Accuracy	25	m
RCS Target size	+3	m <sup>2</sup>

### Technical Specifications (Earthfence/GEO)





Image credit: AGI Inc.



- **Earthfence** custom software offers dashboard style visualisations of time-domain pulse power, velocity imaging profile and pulse train waterfall.

## Thoth Technology Inc.

- Thoth Technology is a Canadian space and defense company founded in 2001.



**THOTH** TECHNOLOGY, INC.

For further information please contact:

Thoth Technology Inc.  
Achray Road, RR6 Pembroke, ON K8A 6W7  
Canada

Tel: +1 (905) 713-2884 ext. 101

Email: [info@thothx.com](mailto:info@thothx.com)

Websites: [www.thothx.com](http://www.thothx.com)



[www.thothx.com](http://www.thothx.com)